



**823251** 12/300

TAFELMES MOMO  
COUTEAU DE TABLE MOMO  
TABLE KNIFE MOMO



5 4 10595 541287

**823252** 12/300

TAFELVORK MOMO  
FOURCHETTE DE TABLE MOMO  
TABLE FORK MOMO



5 4 10595 541270

**823253** 12/300

TAFELLEPEL MOMO  
CUILLERE DE TABLE MOMO  
TABLE SPOON MOMO



5 4 10595 541294

**823254** 12/300

KOFFIELEPEL MOMO  
CUILLER A CAFE MOMO  
TEA SPOON MOMO



5 4 10595 541348

**823255** 12/300

TAARTVORK MOMO  
FOURCHETTE A GATEAU MOMO  
CAKE FORK MOMO



5 4 10595 541300

**823256** 12/300

LONGDRINKLEPEL MOMO  
CUILLER LONGDRINK MOMO  
LONGDRINK SPOON MOMO



5 4 10595 541331

**823257** 12/300

VISMES MOMO  
COUTEAU A POISSON MOMO  
FISH KNIFE MOMO



5 4 10595 541324



**momo**



**823250** 1/6

BESTEK 24 DELIG MOMO  
COUVERTS 24 PIECES MOMO  
24PCS CUTLERY SET MOMO



5 4 10595 541355

**823258** 12/300

VISVORK MOMO  
FOURCHETTE A POISSON MOMO  
FISH FORK MOMO



5 4 10595 541317

**823264** 12/300

DESSERTMES MOMO  
COUTEAU A DESSERT MOMO  
DESSERT KNIFE MOMO



5 4 10595 540013

**823265** 12/300

DESSERTVORK MOMO  
FOURCHETTE A DESSERT MOMO  
DESSERT FORK MOMO



5 4 10595 540020

**823266** 12/300

DESSERTLEPEL MOMO  
CUILLERE A DESSERT MOMO  
DESSERT SPOON MOMO



5 4 10595 540037

**823260** 6/48

LONGDRINKLEPEL SET/6 MOMO  
CUILLER LONGDRINK SET/6 MOMO  
LONGDRINK SPOON SET/6 MOMO



**823261** 6/48

KREEFTENHAAK SET/6 MOMO  
FOURCHETTE A HOMARD SET/6 MOMO  
LOBSTER FORK SET/6 MOMO



**823262** 6/48

SLAKKENVORK SET/6 MOMO  
FOURCHETTE A ESCARGOTS SET/6 MOMO  
SNAIL FORK SET/6 MOMO



**823263** 6/48

OESTERVORK SET/6 MOMO  
FOURCHETTE A HUITRES SET/6 MOMO  
OYSTER FORK SET/6 MOMO





**850104**

2/8

SLAKOM DIEP 25CM  
SALADIER CREUSE 25CM  
SALAD BOWL DEEP 25CM



9 319882 041966

**850105**

2/8

SLAKOM LAAG 30CM  
SALADIER BAS 30CM  
SALAD BOWL SHALLOW 30CM



9 319882 041973



**850106**

6/12

SLAKOM DIEP 17.5CM  
BOL 17.5CM  
SALAD BOWL DEEP 17.5CM



9 319882 041980



**850107**

6/12

SLAKOM DIEP 20CM  
BOL 20CM  
SALAD BOWL DEEP 20CM



9 319882 041997

**850108**

6/24

SLAKOM DIEP 12CM  
BOL 12CM  
SALAD BOWL DEEP 12CM



9 319882 042000

**850109**

6/24

SLAKOM DIEP 15CM  
BOL 15CM  
SALAD BOWL DEEP 15CM




9 319882 042017



**850110**

4/12

SCHOTEL ROND 30CM  
PLAT ROND 30CM  
ROUND PLATTER 30CM



**850137**

6/12

PLAT BORD 27CM COUPE  
ASSIETTE PLATE 27CM COUPE  
DINNER PLATE 27CM COUPE



**850139**

4/24

DESSERTBORD 22CM COUPE  
ASSIETTE A DESSERT 22CM COUPE  
PLATE 22CM COUPE



**850140**

6/36

BROOdBORD 18CM COUPE  
ASSIETTE A PAIN 18CM COUPE  
SIDE PLATE 18CM COUPE



**850138**

6/24

DIEP BORD 20CM COUPE  
ASSIETTE CREUSE 20CM COUPE  
SOUP PLATE 20CM COUPE



**850141**

6/24

CEREALSCHAALTJE 17CM COUPE  
BOL A CEREALES 17CM COUPE  
CEREAL BOWL 17CM COUPE





850116

6/12

OLIE+AZIJN SET  
HUILE+VINAIGRE SET  
OIL+VINEGAR SET



9 319882 042086



850119

6/24

BEKER  
CHOPE  
MUG



9 319882 042116

850120

6/24

KOP+SCHOTEL 0.22L  
TASSE+SOUCOUPE 0.22L  
CUP+SAUCER 0.22L



9 319882 047302

850121

6/36

MOKKAKOP 0.08L+SCHOTEL  
TASSE MOKA 0.08L+SOUJ.  
MOCHA CUP 0.08L+SAUCER



9 319882 042130

850124

6/12

SCHOTEL OVAAL 45X17CM  
PLAT OVAL 45X17CM  
OVAL PLATTER 45X17CM



9 319882 042161

850125

6/12

SCHOTEL OVAAL 38X13CM  
PLAT OVAL 38X13CM  
OVAL PLATTER 38X13CM



9 319882 042178



momo

**850117**

6/24

ZOUT+PEPER SET  
SALIERE+POIVRIER SET  
SALT+PEPPER SET



9 319882 042093



**850111**

6/24

SCHOTEL VIERKANT 18X18CM  
ASSIETTE 18X18CM  
SQUARE PLATTER 18X18CM



9 319882 042031



**850112**

6/12

SCHOTEL VIERKANT 26X26CM  
ASSIETTE 26X26CM  
SQUARE PLATTER 26X26CM



9 319882 042048

**850113**

4/8

SCHOTEL VIERKANT 30X30CM  
ASSIETTE 30X30CM  
SQUARE PLATTER 30X30CM



9 319882 042055

**850114**

2/4

SCHOTEL RECHTH.45X30CM  
PLAT RECT. 45X30CM  
RECT. PLATTER 45X30CM



9 319882 042062

**850115**

6/12

SCHOTEL RECHTH.36X15CM  
PLAT RECT. 36X15CM  
RECT. PLATTER 36X15CM



9 319882 042079



**850142**

6/12

EIERDOP SET/6  
COQUETIER SET/6  
EGG CUP SET/6



9 319882 062329





**850143**

1/6

TAARTSCHOTEL OP VOET 31CM  
PLAT A TARTE SUR PIED 31CM  
FOOTED CAKE PLATE 31CM



**850144**

1/6

ONTBIJTSET KOP+BORD  
SET A DEJEUNER  
SNACK SET



**850145**

1/6

OVENSCHOTEL VIERK.24X24CM  
PLAT A FOUR CARRE 24X24CM  
SQUARE BAKER 24X24CM



**850147**

1/6

OVENSCHOTEL VIERK.28X28CM  
PLAT A FOUR CARRE 28X28CM  
SQUARE BAKER 28X28CM



**850146**

1/6

OVENSCHOTEL RECHTH.33X24CM  
PLAT A FOUR RECT.33X24CM  
RECTANGULAR BAKER 33X24CM



**850148**

12/24

SCHAALTJE 7CM SET/6  
COUPELLE 7CM SET/6  
DIPPING DISH 7CM SET/6



9 319882 062404



**850149**

12/24

SCHAALTJE 9CM SET/4  
COUPELLE 9CM SET/4  
DIPPING DISH 9CM SET/4



9 319882 062411



**850153**

1/12

SCHAALTJE 11CM SET/2  
COUPELLE 11CM SET/2  
DIPPING DISH 11CM SET/2



9 319882 062428

**850154**

1/12

VERDEELSHOTEL 2D KLEIN  
PLAT 2 COMP.PETIT  
2 SECTION CONDIMENT SET



9 319882 062459

**850155**

1/12

VERDEELSHOTEL 2D GROOT  
PLAT 2 COMP.GRAND  
2 SECTION CONDIMENT SET



9 319882 062466



**850152**

1/4

SALADESET 6DLG WIT  
SET A SALADE 6PCS BLANC  
SALAD SET 6PCS ALL WHITE



9 319882 057912

